





GUERRILLASIGNS.COM

Patent Pending



GUERRILLA SIGNS INSTRUCTION MANUAL AND DISCLAIMER



Step 1: Find a location with no buried cables or water lines etc. Carefully remove the Guerrilla Sign from the vehicle and place it on the ground.


Note: the pins holding the arms closed are not shown in any of the images.

Step 2: Remove the drive pin at the bottom of the sign, extend the stake out the bottom of the frame, and insert the drive pin in the large hole near the middle of the sign. Be sure to use a cotter pin to reduce the chance of the drive pin falling out.





Step 3: Lift the frame vertical and use it as a post driver by repeatedly lifting the frame up and ramming it down. Do this until the frame is sturdy but do not put the stake in the ground more than 18 inches.

Step 4: Remove the 4 pins that hold the sign closed (two at the top and two at the bottom) and be careful not to drop them. Raise the arms by holding them near the middle, and being careful not to pinch your fingers on the top of the sign.



Step 5: Insert a pin under an arm to hold the arms up.



Step 6: Attach the face(s) to the arms at the suggested ends (circled) by inserting pins through the face and the respective hole in the arms; be sure that the pins go all the way through the arms. Use cotter pins to secure the pins and face to the frame.

Step 7: Attach the 4th corner of the face(s) by pulling the remaining corner of a face to the remaining end of an arm while lifting up on the arm; the sign will go up higher than you think. Insert the remaining pin from step 5 through the face and all the way through the arm, and secure the pin using the cotter pin. Remove the drive pin from the large hole in the sign allowing the frame to be lowered until it rests on the ground.

Step 8: Enjoy the view.

Step 9: Remove the face and roll it face inward around the provided tube. Secure the arms in position 3 (pins not shown) by inserting the pins into the arms and using the cotter pins to hold them in place. Use the frame as a reverse post driver to remove the stake from the ground.

Step 10: Push the stake back into the frame and place the drive pin back on the bottom.

Step 11: Insert a lock in a hole shown in step 5 to reduce theft. Lock must go all the way through the sign.

Disclaimer: *Caution this sign is intended for responsible adults only because it is made of a heavy metal with sharp edges. Use care and gloves, and do not assume that safety plate is on without first checking as stake could slide out causing injury or damage. Never put the stake into the ground more than 18 inches deep (less than the length of the exposed stake) because of power lines; always call any municipalities about power lines, water lines, cables etc before using. Do not place fingers on the gears. Watch to make sure that pins do not fall out while driving the stake into or out of the ground as this could result in injury. **By using this product you agree to everything below:** You will not hold Guerrilla Signs responsible for any miss-use, and injury or damages that could be caused from use of this product. You understand that any product can be hazardous when used in the wrong way, and thus it is your responsibility to use judgment and caution when using this product. That Guerrilla Signs has provided you with the necessary information to safely use the product. You as the original opener of the product will be responsible for assuring that those who are going to use it will be properly notified of this disclaimer.*